
 01708 556 721

 www.bmengineworks.co.uk

 support@bmengineworks.co.uk

Fitting Instructions for BMW N57 Engines

We are here to help! With over 20 years of experience working on all types of engines, we've encountered every conceivable problem. If you have any questions during the fitting process, please don't hesitate to contact our sales advisors.

1. Important Considerations

Identify the Cause of Failure

Before fitting the replacement engine, try to determine the cause of the original engine failure. This will help you address any underlying issues and prevent damage to the new engine.

Address External Issues

If the failure was due to external factors like coolant leaks or radiator problems, fix these before installing the new engine.

Clean the Oil System

Thoroughly clean the oil filter/heat exchanger housing and replace the oil cooler gasket. Remove all debris from the cooler to avoid damaging the new engine.

Verify Oil Pan Compatibility

Ensure the oil pan (sump) is correct for your BMW model. If necessary, swap the sump and pick-up pipe from your old engine, cleaning them thoroughly.

Replace Seals and Gaskets

Renew injector seals and the rocker cover gasket to prevent leaks

2. Engine Preparation

Prime the Engine Oil

Turn the engine by hand to circulate oil to the top of the engine.

Clean the DPF

It's highly recommended to clean the Diesel Particulate Filter (DPF), especially if the vehicle has over 100,000 miles.

Oil Filter and Oil Specifications

Use the correct oil filter for your N57 engine.

Use the exact specification oil or equivalent. Remember this is a dry fill, so it may require 500ml to 1000ml more oil than a standard service.

3. General Fitting Guide

Starter Motor

Test the starter motor before installation to ensure it's functioning correctly. This will save time and effort if it needs replacement.

Rocker Cover

BMW N57 engines have PCV valves in the rocker cover that can become blocked. Consider replacing the rocker cover to prevent back pressure issues.

Turbochargers

Inspect the turbocharger(s) for oil leaks or excessive shaft play. If in doubt, replace the turbocharger(s), especially on high-mileage vehicles.

Intercooler

Clean the intercooler thoroughly to remove any oil or water residue from the previous engine failure.

Flywheel (Manual Models)

Check the dual-mass flywheel and clutch for wear. The clutch plate should have sufficient material, and the flywheel should have no excessive movement or noise.

Automatic Gearbox

It is highly recommended to replace the gearbox oil and service kit.

Battery

Ensure the battery is fully charged for the initial engine start and diesel system priming.

Final Checks

This guide provides general instructions. Always refer to the official BMW workshop manual for detailed procedures and torque specifications. Develop a system to double-check critical steps, especially when multiple people are working on the vehicle.

We're Here to Help

If you have any questions or need assistance, please don't hesitate to contact us.



01708 556 721



www.bmengineworks.co.uk